

Instructions: Installation of a Public Bike Pump

Instructions:

1. Position the Public Bike Pump at the desired location on the floor and mark out holes.
If installed on paving slabs or bricks, position so that the bolt holes will be drilled in the middle of the brick/slab, not in the joints.
2. Drill 4 x holes just deep enough to fit the anchor – do not drill any deeper, otherwise the bolt will not reach the thread.
3. Expand the anchor using the supplied tool and a hammer.
4. Replace the Pump and tightly screw the security bolts into the threads.



Parts included:

- Public Bike Pump
- Anchors x 4
- Security Bit

Tools required:

- Hammer drill
- Marker
- Bit driver
- Hammer