

Instructions: Installation of a Mini Wall Anchor

1. Position the anchor at the desired location on the wall and mark out holes with a pencil.
You can also use the attached template as a guide.
We recommend installing the anchor at a height of 500mm measured from the bottom of the anchor to the ground.
If installed on brick work, position the anchor so that the bolt holes will be drilled in the middle of the brick, not in the mortar.
2. Drill 2 x 10mm holes deep enough to fit the fixings, ensure these holes are in a straight line.
3. Take the fixings apart, then attach and reassemble them to the back of the anchor. Make sure you do not tighten the fixings as it will cause them to expand.
4. Place the anchor with the fixings into the holes. Tap the fixings gently until the anchor is flush against the wall.
5. Use the hex key to tighten up the fixings to secure the bracket.
6. If you require Mini Wall Anchor to be permanently installed, hammer the ball bearings into the hex socket of the fixings.
Note: the fixings can no longer be undone. To remove them, use an angle grinder to cut the ball bearing out so that the hex socket can be accessed.

Parts included:

- 1x Mini Wall Anchor
- 2x Sleeve wall anchors
- 2x Ball bearings
- 1x Instruction sheet

Tools required:

- Electric drill with 10mm bit
- Pencil
- 5mm Hex key
- Hammer

