

Instructions: Installation of a Wheel Ramp

Instructions:

1. Position the Ramp at the desired location on the floor and mark out holes with a pencil. If installed on paving slabs or bricks, position so that the bolt holes will be drilled in the middle of the brick/slab, not in the joints.
2. The bracket has a hole and a long slot. The long slot attaches to the ramp and the hole to the vertical part of the step. Adjust to fit and tighten the bolt holding the two together.
3. Drill 2 x holes and slot the sleeve anchors in, through the ramp.
4. Expand the anchor tightly using the supplied security bit and a wrench.



Parts included:

- Ramp
- Bracket
- Sleeve Anchors x 2
- Security Bit

Tools required:

- Hammer drill
- Marker
- Spanner
- Hammer
- Bit Driver