

Instructions: Installation of a Vertical Bike Rack

1. Check the wall is secure enough to support the rack. Is it sturdy and able to bear the load of the bikes? Concrete and modern brick walls are best.

2. Position the Vertical Bike Rack at the desired location on the wall and mark out holes with a pencil. We recommend installing the Vertical Bike Rack at a height of 115cm or 145cm measured from the bottom of the rack to the ground.

If installed on brick work, position so that the bolt holes will be drilled in the middle of the brick, not in the brick mortar.

3. Drill 2x 12mm holes deep enough to fit the coach screws.

4. Insert the rawl plugs into the holes.

5. Holding the Vertical Bike Rack up, insert the coach screws through the holes and into the rawl plugs.

6. Ensuring the whole coach screw is inserted, use the adjustable spanner to tighten up the coach screws.

7. Ensure the Vertical Bike Rack is held tightly to the wall with both coach screws. Put the black plastic caps onto the end of the coach screws.

Parts included:

- Cyclehoop Vertical Wall Rack
- Coach Screws x 2
- Rawl plugs x 2
- Black Plastic Caps x 2

Tools required:

- Electric drill
- Pencil
- Adjustable Spanner
- Hammer

