

Instructions: Installation of a Bikeshef

Parts included:

- 1x Bikeshef
- 4x Sleeve wall anchors
- 1x Instruction sheet

Tools required:

- Electric drill
- 11mm Masonary drill bit
- Hex tool
- Sticky tape
- Hammer

Making the Bikeshef permanent:

If you require the Bikeshef to be permanently installed, you can hammer 5mm ball bearings into the hex hole of two diagonally opposed bolts. (Note: the bolts can no longer be undone. To remove, use an angle grinder to cut the ball bearing out so that the alien hole can be accessed.)

Drill holes here...



Before you start:



Wear Eye protection



Use an electric power drill



Switch the drill to hammer mode (if available)




Use a 11mm Masonary drill bit



Item is heavy! Another pair of hands is helpful.

here...



Instructions:

1. Using sticky tape, fix this piece of paper at the desired location of the bike shelf onto the wall. This will act as a template for when you drill the bolt holes.


If installed onto brick work, position the piece of paper so that the bolt holes will be drilled in the middle of the brick, not in the brick joints.

2. Following the drilling template, drill 4 holes deep enough to fit the sleeve anchor. A depth of 6cm is recommended. When completed, remove this piece of paper.


3. Insert the 4 sleeve wall anchors into the holes of the bike shelf. Make sure you do not tighten the sleeve anchors as this will cause them to expand.

4. Carefully, insert the bike shelf with the sleeve wall anchors into the holes in the wall. With a hammer, gently tap each of the wall anchors gently until they are flush against the bike shelf. The bike shelf is not secured onto the wall yet; make sure you have a firm grip of it.

5. Use a hex tool to tighten up the sleeve anchors to secure the bike shelf onto the wall.



here...



and here.